

<STB入力で基礎大梁が大梁で変換されてしまう>

基礎大梁か大梁かの判断は、isFoundation が TRUE になっているのが条件です。

```
<StbGirders>↓  
<StbGirder id="35" name="1FG1" idNode_start="9" idNode_end="23" rotate="0" id_section="17" kind_structure="RC" isFoundation="TRUE"  
<StbGirder id="36" name="1FG1" idNode_start="10" idNode_end="24" rotate="0" id_section="17" kind_structure="RC" isFoundation="TRUE"
```

```
<StbSecBeam_RC id="17" name="FG1" floor="" kind_beam="GIRDER" isFoundation="TRUE"  
<StbSecFigure>↓  
<StbSecHaunch width_start="500" depth_start="900" width_center="500" depth_center="
```

"FALSE" になっている場合は大梁になりますので、出力側の設定を確認してください。

基礎小梁、小梁についても同様です。